ENFORCER® Bluetooth[®] Mullion Keypad with Reader





What's in the Box:

1x SK-B241-PQ ENFORCER Bluetooth® Mullion Keypad with Reader


4x Mounting screws 1x Security screw bit

4x Plastic wall anchors 12x Wire crimps 1x Diode 1x Varistor 1x Quick Installation/Setup Guide 1x Product Specifications

Specifications

Sample	Wiring	Diagram
--------	--------	---------

Operating voltage		9~25 VDC	
Current draw	Standby	60mA@12VDC, 30mA@24VDC	
	Active (max.)	115mA@12VDC, 55mA@24VDC	
Outputs	Form C	2.0A@30VDC	
	Tamper alarm	100mA@30VDC (solid state N.C.)	
Egress input		N.O. Ground	
Door sensor input		N.C. Ground	
Proximity reader		EM 125kHz	
IP Rating		IP65 Weather-resistant	
Enclosure material		Zinc alloy	
Operating humidity		0-95%, non-condensing	
Operating temperature		-4°~122° F (-20°~50° C)	
Dimensions		1 ³ / ₄ "x6"x ⁷ / ₈ " (45x152x23 mm)	
Weight		15.8-oz (447g)	



IMPORTANT NOTES

*To protect the relay, you must install the enclosed diode—with the cathode (striped end — —) toward the positive side—for DC powered locks **OR** install the varistor (MOV, —) for AC powered locks and for electromagnetic locks **unless** your lock has a diode/MOV built in (all SECO-LARM electromagnetic locks have built-in protection). Do not install both. Failure to install as directed will void the warranty. Download the Installation Manual and Administrator Guide from <u>www.seco-larm.com</u> for complete instructions.


[†]Use the blue wire for fail-secure applications and the yellow wire for fail-safe applications. Use electrical tape to insulate the end of any unused wire.






ENFORCER Bluetooth® Mullion Keypad with Reader

Installation and Mounting



Remove Base

Using the security bit, remove the screw and housing base.



Mark Holes for Drilling


Using the base, mark mounting and wiring holes.

```
O ← <sup>5</sup>/<sub>16</sub>" (8mm)
0
                  Approximately
                  11/4" (3cm)
C
         C
```

Drill Holes

Drill the five holes. The wiring hole should be about ø11/4" (ø3cm).





1. Feed Wires into Wall Connect wires and push through the hole in the wall, taking care not to loosen any connectors.

2. Mount Base to Wall Mount the base to the wall using the supplied screws and wall anchors or other screws.

3. Mount Keypad to Base

Slide the device to engage the tab on the top of the base, and secure with the security screw.

The trad FC

The Bluetooth® word mark and logos are registered trademarks owned by trade names are those of their respective owners.	Bluetooth SIG, Inc. and any use of such r	narks by SECO-LARM is under license. Other trademarks and
FCC COMPLIANCE STATEMENT FOR BLUETOOTH MODULE THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPER HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT A		
OPERATION. Notice: The changes or modifications not expressly approved by the party IMPORTANT NOTE: To comply with the FCC RF exposure compliance	responsible for compliance could void the requirements, no change to the antenna of	user's authority to operate the equipment. or the device is permitted. Any change to the antenna or the
device could result in the device exceeding the RF exposure requirements This device complies with Industry Canada licence-exempt RSS standard (2) this device must accept any interference, including interference that ma	(s). Operation is subject to the following two ay cause undesired operation of the device.	wo conditions: (1) this device may not cause interference, and
Le présent appareil est conforme aux CNR d'Industrie Canada applicabl (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'a compromettre le fonctionnement.		
IMPORTANT WARNING: For a weather-resistant installation, ensure that sealed. Incorrect mounting may lead to exposure to rain or moisture insid installers are responsible for ensuring that this product is properly installed	le which could cause a dangerous electric	
IMPORTANT: Users and installers of this product are responsible for ensu and codes. SECO-LARM will not be held responsible for the use of this pro-		
California Proposition 65 Warning: These products may contain chemi harm. For more information, go to <u>www.P65Warnings.ca.gov</u> .	icals which are known to the State of Cali	fornia to cause cancer and birth defects or other reproductive
WARRANTY: This SECO-LARM product is warranted against defects in original customer. SECO-LARM so obligation is limited to the repair or rr Warranty is void if damage is caused by or attributed to acts of God, phy installation, or if for any other reason SECO-LARM determines that such en The sole obligation of SECO-LARM and the purchaser's exclusive rem SECO-LARM be liable for any special, collateral, incidental, or consequent	eplacement of any defective part if the u ysical or electrical misuse or abuse, negle quipment is not operating properly as a re- nedy, shall be limited to the replacement	nit is returned, transportation prepaid, to SECO-LARM. This ct, repair or alteration, improper or abnormal usage, or faulty suit of causes other than defects in material and workmanship. or repair only, at SECO-LARM's option. In no event shall

NOTICE: The SECO-LARM policy is one of continual development and improvement. For that reason, SECO LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints. All trademarks are the property of SECO-LARM U.S.A., Inc. or their respective owners. Copyright © 2024 SECO LARM U.S.A. Inc. All rights reserved.

SECO-LARM[®] U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606 Phone: (949) 261-2999 | (800) 662-0800

Website: www.seco-larm.com Email: sales@seco-larm.com

